

## Appendix B Procedure for Conducting a Pilot Infiltration Test

The Pilot Infiltration Test (PIT) consists of a relatively large-scale infiltration test to better approximate infiltration rates for design of stormwater infiltration facilities. The PIT reduces some of the scale errors associated with relatively small-scale double ring infiltrometer or “stove-pipe” infiltration tests. It is not a standard test but rather a practical field procedure recommended by Ecology’s Technical Advisory Committee.

### B.1 Infiltration Test

6. Excavate the test pit to the depth of the bottom of the proposed infiltration facility. Lay back the slopes sufficiently to avoid caving and erosion during the test.
7. The horizontal surface area of the bottom of the test pit should be approximately 100 square feet. For small drainages and where water availability is a problem smaller areas may be considered as determined by the site professional.
8. Accurately document the size and geometry of the test pit.
9. Install a vertical measuring rod (minimum 5-ft. long) marked in half-inch increments in the center of the pit bottom.
10. Use a rigid 6-inch diameter pipe with a splash plate on the bottom to convey water to the pit and reduce side-wall erosion or excessive disturbance of the pond bottom. Excessive erosion and bottom disturbance will result in clogging of the infiltration receptor and yield lower than actual infiltration rates.
11. Add water to the pit at a rate that will maintain a water level between 3 and 4 feet above the bottom of the pit. A rotometer can be used to measure the flow rate into the pit. A water level of 3 to 4 feet provides for easier measurement and flow stabilization control. However, the depth should not exceed the proposed maximum depth of water expected in the completed facility.
12. Every 15-30 min, record the cumulative volume and instantaneous flow rate in gallons per minute necessary to maintain the water level at the same point (between 3 and 4 feet) on the measuring rod.
13. Add water to the pit until one hour after the flow rate into the pit has stabilized (constant flow rate) while maintaining the same pond water level (usually 17 hours).
14. After the flow rate has stabilized, turn off the water and record the rate of infiltration in inches per hour from the measuring rod data, until the pit is empty.

### B.2 Data Analysis

1. Calculate and record the infiltration rate in inches per hour in 30 minutes or one-hour increments until one hour after the flow has stabilized.

**NOTE:** Use statistical/trend analysis to obtain the hourly flow rate when the flow stabilizes. This would be the lowest hourly flow rate.

2. Apply appropriate correction factors for site heterogeneity, anticipated level of maintenance and treatment to determine the site-specific design infiltration rate (see Table 5 - 16).

**Table 5 - 16: Correction Factors to be Used with In-Situ Infiltration Measurements to Estimate Long-Term Design Infiltration Rates**

Issue	Partial Correction Factor
Site variability and number of locations tested	$CF_v = 1.5 \text{ to } 6$
Degree of long-term maintenance to prevent siltation and bio-buildup	$CF_m = 2 \text{ to } 6$
Degree of influent control to prevent siltation and bio-buildup	$CF_i = 2 \text{ to } 6$

### B.3 Example

The area of the bottom of the test pit is 8.5-ft. by 11.5-ft.

Water flow rate was measured and recorded at intervals ranging from 15 to 30 minutes throughout the test. Between 400 minutes and 1,000 minutes the flow rate stabilized between 10 and 12.5 gallons per minute or 600 to 750 gallons per hour, or an average of  $(9.8 + 12.3) / 2 = 11.1$  inches per hour.

Applying a correction factor of 5.5 for gravelly sand, the design long-term infiltration rate becomes 2 inches per hour, anticipating adequate maintenance and pretreatment.