

NOTES:

- 1. For new pervious concrete sidewalk, place joint directly over centerline of pipe. When placing pipe under existing pervious sidewalk, restoration with impervious concrete will be allowed.
- 2. No mesh reinforcement to be used for pervious sidewalks.
- 3. Storm pipe shall be per the City Stormwater Management Manual Volume 3 for pipes within the right-of-way.

